

Typical Hot Mop Shower Pan Installation Details

Note: Set the drain body level. Do not follow sub-floor if it is out of level.
 Do not grout in strainer. Strainer must remain removable for maintenance.
 Hot mop and drain membrane are not compatible and must not touch each other.

